KIT INSTRUCTIONS

SelfServ™ 90 Printer Blank Plate

7709-K302

Issue A

Revision Record

Issue	Date	Remarks
A	Apr 2016	First Issue

Printer Blank Plate

Introduction

This kit provides the components to add a printer blank plate to the NCR SelfServ™ 90 Kiosk.

Kit Contents

Printer Blank Plate
497-0510630

(2) Screws, M3 x 6, Philips, PH, SEMS
006-8613167

Label - Blank, Coupon/Printer Graphics
497-0510526

60911

# Installation Procedure

1. Open the front of the kiosk.

60847

2. Install the printer blank plate. Secure with screws (2).

Printer Blank Plate

60913

3. Cover the Printer Graphics with the Blank Label. When attaching the blank label, please observe the following:

   • The top edge of the label is parallel to the printer opening.

   • The label is smooth, straight and not crumpled.

   • The whole printer graphic is covered and no part is visible exceeding the blank label.

Blank Label

60908